

220千伏变电站主变负荷开放信息								
说明： 1. 主变可开放容量=主变额定容量*0.8-上年度至上月出现过的最大负荷（正常方式）-本月新接入的负荷+本月转走的负荷。 2. 主变中、低压侧可开放容量不得大于高压侧可开放容量。 3. 主变中、低压侧可开放容量不具备同时性，同时接入容量不得大于高压侧可开放容量。 4. 可开放容量每月滚动更新，对新建变电站、主变增容、主变扩建、新出线路、线路改接等造成可开放容量变化时，应在备注中注明。								
序号	变电站	变压器	主变绕组	额定容量 (MVA)	最高负荷 (MVA)	负载率 (%)	可开放容量 (MVA)	备注
1	岙山站	#1主变	高	150	99	66	21	
			中	150	49	33	21	
			低	75	0	0	21	
		#2主变	高	240	156	65	36	
			中	240	148	62	36	
			低	120	31	26	36	
		#3主变	高	180	133	74	11	
			中	180	125	69	11	
			低	90	37	41	11	
2	大庄站	#1主变	高	150	116	78	4	
			中	150	89	59	4	
			低	75	56	74	4	
		#2主变	高	150	121	81	0	
			中	150	85	57	0	
			低	75	49	65	0	

		#3主变	高	180	142	79	2	
			中	180	117	65	2	
			低	90	34	38	2	
3	岛厂站	#1主变	高	180	87	48	57	
			中	180	86	48	57	
			低	90	10	11	57	
		#2主变	高	180	127	70	17	
			中	180	115	64	17	
			低	90	14	15	17	
4	董家站	#1主变	高	240	150	63	42	
			中	240	115	48	42	
			低	120	36	30	42	
		#2主变	高	240	135	56	57	
			中	240	121	51	57	
			低	120	35	30	57	
		#3主变	高	240	124	52	68	
			中	240	118	49	68	
			低	120	32	27	64	
5	风光站	#1主变	高	240	193	80	0	
			中	240	120	50	0	
			低	120	103	86	0	
			高	240	186	78	6	

		#2主变	中	240	133	55	6	
			低	120	117	98	6	
6	贡口站	#2主变	高	240	174	72	18	
			中	240	163	68	18	
			低	120	41	34	18	
		#3主变	高	240	215	90	0	
			中	240	205	85	0	
			低	120	25	21	0	
7	官路站	#1主变	高	180	157	87	0	
			中	180	127	71	0	
			低	180	56	31	0	
		#2主变	高	180	140	78	4	
			中	180	119	66	4	
			低	180	46	25	4	
8	广源站	#1主变	高	180	119	66	25	
			中	180	97	54	25	
			低	90	39	43	25	
		#2主变	高	180	122	68	22	
			中	180	110	61	22	
			低	90	44	49	22	
		#3主变	高	240	211	79	0	
			中	240	211	79	0	

			低	120	0	0	0	广源站#3主变10kV侧不带负荷
9	海河站	#1主变	高	240	152	63	40	
			中	240	102	43	40	
			低	120	59	49	37	
		#2主变	高	240	146	61	46	
			中	240	116	48	46	
			低	120	50	41	46	
10	虎山站	#1主变	高	150	109	73	11	
			中	150	49	33	11	
			低	150	84	56	11	
		#2主变	高	150	143	95	0	
			中	150	66	44	0	
			低	150	118	79	0	
		#3主变	高	180	133	74	11	
			中	180	77	43	11	
			低	150	85	57	11	
11	黄埠站	#1主变	高	180	145	80	0	
			中	180	103	57	0	
			低	120	49	41	0	
		#2主变	高	180	142	79	2	
			中	180	107	60	2	
			低	120	50	42	2	

12	即墨站	#1主变	高	180	155	86	0	
			中	180	108	60	0	
			低	90	76	84	0	
		#2主变	高	180	152	85	0	
			中	180	125	69	0	
			低	90	59	66	0	
13	胶州站	#1主变	高	180	146	81	0	
			中	180	111	62	0	
			低	90	55	61	0	
		#2主变	高	180	144	80	0	
			中	180	125	69	0	
			低	90	40	44	0	
14	空港站	#1主变	高	240	198	82	0	
			中	240	169	70	0	
			低	120	42	35	0	
		#2主变	高	240	209	87	0	
			中	240	190	79	0	
			低	120	45	37	0	
		#1主变	高	240	194	81	0	
			中	240	175	73	0	
			低	120	58	48	0	
			高	240	198	82	0	

15	匡正站	#2主变	中	240	170	71	0	
			低	120	38	32	0	
		#3主变	高	240	181	75	11	
			中	240	180	75	11	
			低	120	0	0	11	
16	莱西站	#1主变	高	180	155	86	0	
			中	180	135	75	0	
			低	90	41	46	0	
		#2主变	高	240	172	72	20	业扩及夏季空调负荷增加
			中	240	164	68	20	业扩及夏季空调负荷增加
			低	120	10	8	20	
17	李山站	#1主变	高	150	109	73	11	
			低	150	106	71	11	
		#2主变	高	150	128	85	0	
			低	150	125	83	0	
		#3主变	高	150	122	81	0	
			低	150	121	81	0	
18	马山站	#1主变	高	180	121	67	23	
			中	180	83	46	23	
			低	90	49	54	23	
		#2主变	高	180	147	82	0	
			中	180	127	71	0	

			低	90	43	48	0	
		#3主变	高	240	164	68	28	
			中	240	149	62	28	
			低	120	18	15	28	
19	南京路站	#1主变	高	240	105	44	87	
			中	240	79	33	87	
			低	72	23	32	35	
		#2主变	高	240	138	57	54	
			中	240	127	53	54	
			低	72	14	19	44	
		#3主变	高	240	138	58	54	
			低	240	139	58	53	
		#4主变	高	240	170	71	22	
			中	240	154	64	22	
			低	72	14	19	22	
20	挪城站	#1主变	高	180	120	67	24	
			中	180	97	54	24	
			低	90	28	31	24	
		#2主变	高	180	126	70	18	
			中	180	112	62	18	
			低	90	24	26	18	
			高	180	156	87	0	

21	平度站	#1主变	中	180	119	66	0	
			低	90	47	53	0	
		#2主变	高	180	160	89	0	
			中	180	99	55	0	
			低	90	68	75	0	
22	前湾站	#1主变	高	240	231	96	0	
			中	240	230	96	0	
			低	120	0	0	0	前湾站35kV不带负荷
		#2主变	高	240	222	93	0	
			中	240	221	92	0	
			低	120	0	0	0	前湾站35kV不带负荷
23	瑞金站	#2主变	高	240	147	61	45	
			中	240	122	51	45	
			低	120	39	33	45	
		#3主变	高	240	171	71	21	
			中	240	155	65	21	
			低	120	37	31	21	
24	上程站	#1主变	高	240	117	49	75	
			中	240	70	29	75	
			低	120	37	31	59	
		#2主变	高	240	113	47	79	
			中	240	101	42	79	

			低	120	30	25	66	
25	市中站	#1主变	高	240	165	69	27	
			低	240	164	69	27	
		#2主变	高	240	174	73	18	
			低	240	174	73	18	
26	双桥站	#1主变	高	180	152	84	0	
			中	180	145	81	0	
			低	90	32	36	0	
		#2主变	高	180	158	88	0	业扩及夏季空调负荷增加
			中	180	140	78	0	业扩及夏季空调负荷增加
			低	90	30	33	0	
27	水清沟站	#1主变	高	180	149	83	0	
			低	180	149	83	0	
		#2主变	高	180	126	70	18	
			低	180	120	67	18	
		#3主变	高	180	108	60	36	
			低	180	109	60	36	
		#4主变	高	240	0	0	240	
			中	240	0	0	240	
			低	120	0	0	120	
		#1主变	高	150	144	96	0	
			中	150	98	65	0	

28	唐田站		低	75	53	71	0	
		#2主变	高	150	130	87	0	
			中	150	93	62	0	
			低	75	76	101	0	
29	团岛站	#1主变	高	240	113	47	79	
			低	240	112	47	79	
		#2主变	高	240	141	59	52	
			低	240	140	58	52	
30	旺屯站	#1主变	高	180	146	81	0	
			中	180	125	69	0	
			低	90	37	41	0	
		#2主变	高	180	154	85	0	
			中	180	104	58	0	
			低	90	54	60	0	
		#3主变	高	240	206	86	0	
			中	240	204	85	0	
			低	120	21	18	0	
31	午山站	#1主变	高	150	117	78	3	
			低	150	114	76	3	
		#2主变	高	150	124	83	0	
			低	150	122	82	0	
		#2主变	高	240	164	69	28	

		#5主变	低	240	165	69	27	
32	西林站	#1主变	高	180	153	85	0	
			中	180	100	55	0	
			低	90	70	78	0	
		#2主变	高	180	165	91	0	
			中	180	104	58	0	
			低	90	60	67	0	
33	伊春站	#1主变	高	240	193	80	0	
			低	240	189	79	0	
		#2主变	高	240	181	76	11	
			低	240	167	70	11	
34	宜川站	#1主变	高	240	145	60	47	
			低	240	146	61	46	
		#2主变	高	240	146	61	46	
			低	240	146	61	46	
35	张楼站	#1主变	高	240	116	48	76	
			中	240	90	38	76	
			低	120	26	22	70	
		#2主变	高	240	173	72	19	
			中	240	170	71	19	
			低	120	16	14	19	
			高	150	93	62	27	

36	珠山站	#1主变	中	150	44	29	27	
			低	75	36	49	24	
		#2主变	高	180	125	69	19	
			中	180	85	47	19	
			低	90	71	78	2	
		#3主变	高	180	155	86	0	
			中	180	138	76	0	
37	开城站	#2主变	高	240	187	78	5	
			中	240	182	76	5	
			低	120	8	7	5	
		#3主变	高	240	162	68	30	
			中	240	161	67	30	
			低	120	26	22	30	
38	科创站	#2主变	高	240	135	56	57	
			中	240	125	52	57	
			低	120	16	13	57	
		#3主变	高	240	127	53	65	
			中	240	121	50	65	
			低	120	22	18	65	
39	站	#1主变	高	240	149	62	43	
			中	240	124	52	43	
			低	120	30	25	43	

39	涌来站	#2主变	高	240	163	68	29	
			中	240	142	59	29	
			低	120	21	18	29	
40	尚德站	#1主变	高	240	76	32	116	
			中	240	75	31	116	
			低	120	13	11	83	
		#2主变	高	150	95	64	25	
			中	150	95	63	25	
			低	90	4	5	25	
41	星火站	#1主变	高	240	157	66	35	
			中	240	146	61	35	
			低	120	22	18	35	
		#2主变	高	240	148	62	44	
			中	240	141	59	44	
			低	120	16	13	44	
42	郁秩站	#1主变	高	240	53	22	139	
			中	240	53	22	139	
			低	120	0	0	96	
		#2主变	高	240	109	45	83	
			中	240	108	45	83	
			低	120	0	0	83	

110千伏变电站主变负荷开放信息

说明：

- 1. 主变可开放容量=主变额定容量*0.8-上年度至上月出现过的最大负荷（正常方式）-本月新接入的负荷+本月转走的负荷。
- 2. 主变中、低压侧可开放容量不得大于高压侧可开放容量。
- 3. 主变中、低压侧可开放容量不具备同时性，同时接入容量不得大于高压侧可开放容量。
- 4. 可开放容量每月滚动更新，对新建变电站、主变增容、主变扩建、新出线路、线路改接等造成可开放容量变化时，应在备注中注明。

序号	变电站	变压器	主变绕组	额定容量 (MVA)	最高负荷 (MVA)	负载率 (%)	可开放容量 (MVA)	备注
1	岙东站	#1主变	高	63.0	47	75	3	
			中	63.0	24	37	3	
			低	44.1	32	73	3	
		#2主变	高	63.0	43	68	7	
			中	63.0	18	29	7	
			低	44.1	28	63	7	
2	北曲站	#1主变	高	63.0	60	95	0	
			低	63.0	60	95	0	
		#2主变	高	63.0	57	90	0	
			低	63.0	57	90	0	
3	城阳站	#1主变	高	63.0	46	72	5	
			中	63.0	21	33	5	
			低	42.2	27	65	5	
		#2主变	高	63.0	57	90	0	
			中	63.0	25	40	0	

			低	42.2	27	64	0	
4	程港站	#1主变	高	63.0	25	39	26	
			中	31.5	21	65	5	
			低	31.5	5	17	20	
		#2主变	高	63.0	20	32	30	
			中	31.5	16	51	9	
			低	31.5	7	24	18	
5	创新站	#1主变	高	63.0	37	59	13	
			低	63.0	37	59	13	
		#2主变	高	63.0	40	63	11	
			低	63.0	40	63	11	
6	春阳站	#1主变	高	63.0	48	76	2	
			中	63.0	13	21	2	
			低	63.0	38	60	2	
		#2主变	高	63.0	37	59	13	
			中	63.0	/	/	/	
			低	63.0	37	59	13	
7	大洋站	#1主变	高	50.0	11	22	29	
			低	50.0	12	24	28	
		#2主变	高	50.0	9	18	31	
			低	50.0	9	18	31	
		#1主变	高	63.0	19	30	31	

8	汾阳路站	#1主变	低	63.0	18	29	31	
		#2主变	高	63.0	13	21	37	
			低	63.0	13	21	37	
9	古庙站	#1主变	高	63.0	52	82	0	
			中	44.1	22	49	0	
			低	63.0	31	49	0	
		#2主变	高	63.0	37	59	13	
			中	44.1	9	20	13	
			低	63.0	33	52	13	
10	航空城站	#1主变	高	63.0	25	40	25	
			低	63.0	25	39	25	
		#2主变	高	63.0	27	42	24	
			低	63.0	26	41	24	
11	机电工业园站	#1主变	高	63.0	47	75	3	
			中	63.0	22	34	3	
			低	44.1	37	84	0	
		#2主变	高	63.0	41	65	9	
			中	63.0	3	5	9	
			低	44.1	38	86	0	
12	棘洪滩站	#1主变	高	50.0	22	44	18	
			低	50.0	22	44	18	
		#2主变	高	50.0	19	37	21	

		#4主变	低	50.0	19	37	21	
13	马戈庄站	#1主变	高	63.0	37	58	14	
			中	63.0	26	42	14	
			低	63.0	30	47	14	
		#2主变	高	63.0	40	63	11	
			中	63.0	9	14	11	
			低	63.0	32	51	11	
14	南宅站	#1主变	高	63.0	59	94	0	
			中	63.0	32	51	0	
			低	63.0	26	41	0	
		#2主变	高	63.0	48	76	3	
			中	63.0	34	54	3	
			低	63.0	15	24	3	
15	田村站	#1主变	高	63.0	52	82	0	
			中	31.5	25	80	0	
			低	31.5	28	89	0	
		#2主变	高	63.0	47	74	4	
			中	31.5	24	78	1	
			低	31.5	26	81	0	
16	湾头站	#1主变	高	63.0	17	27	33	
			低	63.0	17	27	33	
		#2主变	高	63.0	30	48	20	

		#4主变	低	63.0	30	48	20	
17	文阳路站	#1主变	高	63.0	41	65	9	
			中	63.0	15	24	9	
			低	44.1	26	59	9	
		#2主变	高	63.0	39	62	11	
			中	63.0	18	29	11	
			低	44.1	21	47	11	
18	杏杭站	#1主变	高	63.0	30	48	20	
			低	63.0	30	48	20	
		#2主变	高	63.0	26	41	24	
			低	63.0	26	41	24	
19	玉皇岭站	#1主变	高	63.0	33	52	18	
			中	63.0	0	0	18	
			低	63.0	33	52	18	
		#2主变	高	63.0	32	51	18	
			中	63.0	0	0	18	
			低	42.2	32	76	2	
20	中城站	#1主变	高	63.0	28	44	22	
			中	63.0	1	2	22	
			低	63.0	27	43	22	
		#2主变	高	63.0	30	48	20	
			中	63.0	3	5	20	

			低	63.0	26	41	20	
21	卓越站	#1主变	高	63.0	29	46	22	
			低	63.0	29	45	22	
		#2主变	高	63.0	36	57	15	
			低	63.0	35	56	15	
22	河洛埠站	#1主变	高	63.0	29	45	22	
			低	63.0	29	45	22	
		#2主变	高	63.0	23	36	28	
			低	63.0	23	36	28	
23	黄山站	#1主变	高	63.0	41	66	9	
			低	63.0	41	66	9	
		#2主变	高	63.0	44	70	7	
			低	63.0	44	70	6	
24	开发区站	#1主变	高	50.0	32	64	8	
			低	50.0	32	64	8	主变低压侧CT2000/5
		#2主变	高	50.0	31	62	9	
			低	50.0	31	62	9	主变低压侧CT2000/5
		#3主变	高	50.0	43	86	0	
			低	50.0	43	86	0	
25	昆仑山站	#1主变	高	63.0	34	54	16	
			低	63.0	34	54	16	
		#2主变	高	63.0	37	59	13	

		#4主变	低	63.0	37	59	13	
26	两埠岸站	#1主变	高	63.0	31	49	20	
			低	63.0	31	49	20	
		#2主变	高	63.0	23	36	28	
			低	63.0	23	36	28	
27	龙泉站	#1主变	高	63.0	29	46	21	
			中	63.0	15	24	21	
			低	44.1	15	34	20	
		#2主变	高	63.0	32	51	18	
			中	63.0	13	21	18	
			低	44.1	22	50	13	
28	南港站	#1主变	高	63.0	13	20	38	
			低	63.0	11	17	38	
		#2主变	高	63.0	11	18	39	
			低	63.0	10	17	39	
29	沧口站	#1主变	高	31.5	27	86	0	
			低	31.5	27	86	0	
		#2主变	高	31.5	20	63	5	
			低	31.5	20	63	5	
30	南庄站	#1主变	高	63.0	30	48	20	
			中	63.0	11	17	20	
			低	63.0	20	32	20	

30	南江站	#2主变	高	63.0	35	56	15	
			中	63.0	21	33	15	
			低	63.0	14	22	15	
31	富源站	#1主变	高	50.0	32	64	8	
			中	50.0	26	52	8	
			低	50.0	10	20	8	
		#2主变	高	50.0	19	38	21	
			中	50.0	14	28	21	
			低	50.0	12	24	21	
		#3主变	高	50.0	38	76	2	
			中	50.0	26	53	2	
			低	50.0	12	24	2	
32	石雀滩站	#1主变	高	63.0	32	51	18	
			低	63.0	32	51	18	
		#2主变	高	63.0	33	52	17	
			低	63.0	33	52	17	
33	辛安站	#1主变	高	50.0	45	91	0	
			中	50.0	17	33	0	
			低	50.0	29	59	0	
		#2主变	高	50.0	30	60	10	
			中	50.0	16	32	10	
			低	50.0	16	32	10	

34	新街口站	#1主变	高	63.0	52	83	0	
			中	63.0	39	62	0	
			低	63.0	27	43	0	
		#2主变	高	63.0	58	91	0	
			中	63.0	43	68	0	
			低	63.0	30	48	0	
35	薛家岛站	#1主变	高	50.0	35	70	5	
			中	50.0	16	32	5	
			低	50.0	26	52	5	
		#2主变	高	50.0	41	82	0	
			中	50.0	22	44	0	
			低	50.0	21	42	0	
36	保税区站	#1主变	高	50.0	24	48	16	
			低	50.0	24	48	16	
		#2主变	高	50.0	23	47	17	
			低	50.0	23	46	17	
37	黄岛. 泊里站	#1主变	高	63.0	30	48	20	
			中	63.0	7	11	20	
			低	63.0	23	37	20	
		#2主变	高	63.0	27	43	23	
			中	63.0	8	13	23	
			低	63.0	19	30	23	

38	黄岛. 城南站	#1主变	高	50.0	31	62	9	
			中	50.0	19	38	9	
			低	50.0	12	24	9	
		#2主变	高	50.0	11	22	29	
			中	50.0	7	14	29	
			低	50.0	4	8	29	
39	黄岛. 公园站	#1主变	高	63.0	45	71	6	
			低	63.0	45	71	6	
		#2主变	高	63.0	31	49	19	
			低	63.0	31	49	19	
40	黄岛. 顾家站	#1主变	高	50.0	34	68	6	
			中	50.0	4	8	6	
			低	50.0	30	60	6	
		#2主变	高	50.0	30	60	10	
			中	50.0	4	8	10	
			低	50.0	26	52	10	
		#3主变	高	50.0	18	36	22	
			低	50.0	18	36	22	
41	黄岛. 姜家站	#1主变	高	50.0	45	89	0	
			低	50.0	45	89	0	
		#2主变	高	50.0	30	60	10	
			低	50.0	30	60	10	

42	黄岛. 胶南站	#1主变	高	50.0	18	36	22	
			中	50.0	0	0	22	
			低	50.0	18	36	22	
		#2主变	高	50.0	25	50	15	
			中	50.0	0	0	15	
			低	50.0	25	50	15	
43	黄岛. 灵珠站	#1主变	高	63.0	13	21	37	
			中	63.0	0	0	37	
			低	63.0	13	21	37	
		#2主变	高	63.0	19	30	31	
			中	63.0	0	0	31	
			低	63.0	19	30	31	
44	黄岛. 龙湾站	#1主变	高	63.0	5	8	45	
			中	63.0	4	6	45	
			低	63.0	1	2	45	
		#2主变	高	63.0	16	25	34	
			中	63.0	0	0	34	
			低	63.0	16	25	34	
45	黄岛. 麦墩站	#1主变	高	63.0	26	41	24	
			低	63.0	26	41	24	
		#2主变	高	63.0	27	43	23	
			低	63.0	27	43	23	

46	黄岛. 水城站	#1主变	高	63.0	50	79	0	
			低	63.0	50	79	0	
		#2主变	高	63.0	53	84	0	
			低	63.0	53	84	0	
47	黄岛. 王台站	#1主变	高	50.0	36	72	4	
			中	50.0	10	20	4	
			低	50.0	26	52	4	
		#2主变	高	63.0	43	68	7	
			中	63.0	23	37	7	
			低	63.0	20	32	7	
48	黄岛. 卫西站	#1主变	高	50.0	29	58	11	
			低	50.0	29	58	11	
		#2主变	高	31.5	24	76	1	
			低	31.5	24	76	1	
49	黄岛. 星光站	#1主变	高	63.0	8	13	42	
			低	63.0	8	13	42	
		#2主变	高	63.0	8	13	42	
			低	63.0	8	13	42	
50	黄岛. 隐珠站	#1主变	高	63.0	43	68	7	
			中	63.0	25	40	7	
			低	63.0	18	29	7	
			高	63.0	48	76	2	

		#2主变	中	63.0	34	54	2	
			低	63.0	14	22	2	
51	黄岛. 汕上站	#1主变	高	63.0	17	27	33	
			低	63.0	17	27	33	
		#2主变	高	63.0	15	23	36	
			低	63.0	15	23	36	
52	黄岛. 影都站	#1主变	高	63.0	18	29	32	
			低	63.0	18	29	32	
		#2主变	高	63.0	11	17	40	
			低	63.0	11	17	40	
53	黄岛. 世纪站	#1主变	高	63.0	25	40	25	
			低	63.0	25	40	25	
		#2主变	高	63.0	22	35	28	
			低	63.0	22	35	28	
54	黄岛. 藏马站	#1主变	高	63.0	5	8	45	
			低	63.0	5	8	45	
		#2主变	高	63.0	5	8	45	
			低	63.0	5	8	45	
55	黄岛. 胡家山站	#1主变	高	63.0	1	2	49	
			低	63.0	1	2	49	
		#2主变	高	63.0	4	6	46	
			低	63.0	4	6	46	

56	黄岛. 画家站	#1主变	高	63.0	8	13	42	
			低	63.0	8	13	42	
		#2主变	高	63.0	8	13	42	
			低	63.0	8	13	42	
57	即墨. 北安站	#1主变	高	50.0	44	88	0	
			低	50.0	44	88	0	
		#2主变	高	50.0	42	84	0	
			低	50.0	42	84	0	
		#3主变	高	50.0	29	58	11	
			低	50.0	29	58	11	
58	即墨. 北山站	#1主变	高	63.0	35	56	15	
			低	63.0	35	56	15	
		#2主变	高	63.0	26	41	24	
			低	63.0	26	41	24	
59	即墨. 大信站	#1主变	高	63.0	23	37	27	
			中	63.0	5	8	27	
			低	63.0	18	29	27	
		#2主变	高	50.0	23	46	17	
			中	50.0	6	12	17	
			低	25.0	16	64	4	
		#1主变	高	50.0	20	40	20	
			中	50.0	15	30	20	

60	即墨.店集站		低	25.0	15	60	5	
		#2主变	高	50.0	30	60	10	
			中	50.0	14	28	10	
			低	25.0	16	62	4	
61	即墨.官庄站	#1主变	高	20.0	11	55	5	
			低	20.0	11	54	5	
		#2主变	高	31.5	18	57	7	
			低	31.5	18	57	7	
62	即墨.郭庄站	#1主变	高	50.0	37	74	3	
			低	50.0	37	74	3	
		#2主变	高	50.0	44	88	0	
			低	50.0	44	88	0	
63	即墨.国建站	#1主变	高	50.0	36	72	4	
			低	50.0	36	72	4	
		#2主变	高	50.0	41	82	0	
			低	50.0	41	82	0	
64	即墨.鹤山站	#1主变	高	50.0	29	59	11	
			低	50.0	29	59	11	
		#2主变	高	50.0	26	52	14	
			低	50.0	26	52	14	
65	即墨.横河站	#1主变	高	50.0	40	80	0	
			低	50.0	40	80	0	

65	即墨. 慎阳站	#2主变	高	50.0	26	52	14	
			低	50.0	26	52	14	
66	即墨. 花园站	#1主变	高	63.0	9	14	41	
			低	63.0	9	14	41	
		#2主变	高	63.0	15	24	35	
			低	63.0	15	24	35	
67	即墨. 华瑞站	#1主变	高	63.0	2	3	49	
			低	63.0	2	3	48	
		#2主变	高	63.0	8	13	42	
			低	63.0	8	13	42	
68	即墨. 佳源站	#1主变	高	63.0	44	70	6	
			低	63.0	44	70	6	
		#2主变	高	63.0	50	79	0	
			低	63.0	50	79	0	
69	即墨. 蓝村站	#1主变	高	50.0	31	62	9	
			低	50.0	31	62	9	
		#2主变	高	31.5	18	57	7	
			低	31.5	18	57	7	
		#3主变	高	50.0	29	58	11	
			低	50.0	29	58	11	
		#1主变	高	63.0	31	49	19	
			低	63.0	31	49	19	

70	即墨. 蓝谷站	#2主变	高	63.0	25	40	25	
			低	63.0	25	40	25	
		#3主变	高	63.0	26	41	24	
			低	63.0	26	41	24	
		#4主变	高	63.0	24	38	26	
			低	63.0	24	38	26	
71	即墨. 刘家庄站	#1主变	高	31.5	12	38	13	
			低	31.5	12	38	13	
		#2主变	高	31.5	11	35	14	
			低	31.5	11	35	14	
72	即墨. 龙山站	#1主变	高	50.0	40	80	0	
			低	50.0	40	80	0	
		#2主变	高	50.0	43	86	0	
			低	50.0	43	86	0	
73	即墨. 陆港站	#1主变	高	63.0	24	38	26	
			低	63.0	24	38	26	
		#2主变	高	63.0	24	38	26	
			低	63.0	24	38	26	
74	即墨. 普东站	#1主变	高	50.0	36	72	4	
			低	50.0	36	72	4	
		#2主变	高	50.0	19	38	21	
			低	50.0	19	38	21	

75	即墨. 石门站	#1主变	高	50.0	21	42	19	
			低	50.0	21	42	19	
		#3主变	高	50.0	29	58	11	
			低	50.0	29	58	11	
76	即墨. 水泊站	#1主变	高	50.0	7	13	33	
			低	50.0	7	13	33	
		#2主变	高	31.5	15	48	10	
			低	31.5	15	48	10	
77	即墨. 太祉庄站	#1主变	高	31.5	16	51	9	
			中	31.5	9	29	9	
			低	15.8	5	31	8	
		#2主变	高	20.0	13	65	3	
			中	20.0	13	65	3	
			低	10.0	0	0	3	
78	即墨. 田横站	#1主变	高	31.5	22	70	3	
			中	31.5	21	67	3	
			低	31.5	3	10	3	
		#3主变	高	31.5	16	51	9	
			中	31.5	11	35	9	
			低	31.5	4	13	9	
		#1主变	高	63.0	52	83	0	
			中	63.0	32	51	0	

79	即墨. 文化路站	#2主变	低	63.0	22	35	0	
			高	63.0	50	79	0	
			中	63.0	30	48	0	
			低	31.5	21	67	0	
80	即墨. 夏堤河站	#1主变	高	50.0	37	75	3	
			低	50.0	37	75	3	
		#2主变	高	50.0	35	70	5	
			低	50.0	35	70	5	
		#3主变	高	50.0	36	72	4	
			低	50.0	36	72	4	
81	即墨. 新生站	#1主变	高	63.0	22	35	28	
			低	63.0	22	35	28	
		#2主变	高	63.0	34	54	16	
			低	63.0	34	54	16	
82	即墨. 学苑站	#1主变	高	63.0	13	21	37	
			低	63.0	13	21	37	
		#2主变	高	63.0	15	24	35	
			低	63.0	15	24	35	
83	即墨. 演泉站	#1主变	高	50.0	40	80	0	
			低	50.0	40	80	0	
		#2主变	高	50.0	25	50	15	
			低	50.0	25	50	15	

84	即墨. 玉石站	#1主变	高	50.0	38	76	2	
			低	50.0	38	76	2	
		#2主变	高	50.0	33	66	7	
			低	50.0	33	66	7	
		#3主变	高	63.0	7	11	43	
			低	63.0	7	11	43	
85	即墨. 赵家岭站	#1主变	高	50.0	38	76	2	
			低	50.0	38	76	2	
		#2主变	高	50.0	36	72	4	
			低	50.0	36	72	4	
86	胶州. 艾山站	#1主变	高	50.0	31	61	9	
			中	50.0	7	14	9	
			低	50.0	24	49	9	
		#2主变	高	50.0	31	62	9	
			中	50.0	10	20	9	
			低	50.0	26	53	9	
87	胶州. 北郊站	#1主变	高	63.0	43	68	8	
			中	63.0	28	44	8	
			低	63.0	19	30	8	
		#2主变	高	63.0	44	69	7	
			中	63.0	14	23	7	
			低	63.0	31	49	7	

88	胶州. 大寨站	#1主变	高	50.0	30	60	10	
			低	50.0	30	60	10	
		#2主变	高	50.0	32	65	8	
			低	50.0	32	65	8	
89	胶州. 阜安站	#1主变	高	50.0	29	57	11	
			低	50.0	29	57	11	
		#2主变	高	50.0	25	50	15	
			低	50.0	25	50	15	
90	胶州. 沽河站	#1主变	高	50.0	38	75	3	
			中	50.0	0	0	3	
			低	50.0	38	75	3	
		#2主变	高	50.0	37	74	3	
			中	50.0	0	0	3	
			低	50.0	37	74	3	
91	胶州. 和平站	#1主变	高	50.0	28	56	12	
			中	50.0	13	26	12	
			低	50.0	16	32	12	
		#2主变	高	50.0	24	48	16	
			中	50.0	12	24	16	
			低	50.0	0	0	16	接线方式更改
		#1主变	高	63.0	57	90	0	
			中	63.0	31	50	0	

92	胶州. 胶西站	#2主变	低	63.0	28	44	0	
			高	50.0	40	80	0	
			中	50.0	14	28	0	
			低	50.0	30	60	0	
		#3主变	高	50.0	25	50	15	
			中	50.0	0	0	15	
			低	50.0	25	50	15	
93	胶州. 南郊站	#1主变	高	50.0	45	90	0	
			中	50.0	30	60	0	
			低	50.0	31	62	0	
		#2主变	高	63.0	50	79	0	
			中	63.0	50	79	0	
			低	63.0	0	0	0	
94	胶州. 铺集站	#1主变	高	50.0	44	89	0	
			中	50.0	31	61	0	
			低	50.0	27	53	0	
		#2主变	高	50.0	41	82	0	
			中	50.0	23	45	0	
			低	50.0	19	37	0	
95	胶州. 白湖站	#1主变	高	50.0	24	48	16	
			中	50.0	16	32	16	
			低	50.0	9	18	16	

95	胶州. 永川路站	#2主变	高	50.0	26	53	14	
			中	50.0	12	24	14	
			低	50.0	17	34	14	
96	胶州. 少海站	#1主变	高	50.0	17	34	23	
			低	50.0	17	34	23	
		#2主变	高	50.0	22	43	18	
			低	50.0	20	39	18	
97	胶州. 云溪站	#1主变	高	50.0	32	64	8	
			低	50.0	32	64	8	
		#2主变	高	50.0	41	82	0	
			低	50.0	27	54	0	
98	胶州. 张应站	#1主变	高	50.0	41	83	0	
			中	50.0	40	80	0	
			低	50.0	4	8	0	
		#2主变	高	50.0	19	38	21	
			中	50.0	12	25	21	
			低	50.0	10	20	21	
99	胶州. 长江路站	#1主变	高	50.0	38	76	2	
			中	50.0	17	34	2	
			低	50.0	25	50	2	
		#2主变	高	50.0	40	80	0	
			中	50.0	20	40	0	

			低	50.0	23	46	0	
100	胶州. 中云站	#1主变	高	50.0	46	93	0	
			中	50.0	19	38	0	
			低	50.0	46	93	0	
		#2主变	高	50.0	47	94	0	
			中	50.0	32	64	0	
			低	50.0	19	38	0	
101	胶州. 广东站	#1主变	高	63.0	25	40	25	
			低	63.0	25	40	25	
		#2主变	高	63.0	25	39	26	
			低	63.0	25	39	26	
102	胶州. 泰州站	#1主变	高	63.0	45	71	5	
			低	63.0	43	68	5	
		#2主变	高	63.0	32	51	18	
			低	63.0	32	51	18	
103	胶州. 如意站	#1主变	高	63.0	13	21	37	
			低	63.0	13	21	37	
		#2主变	高	63.0	8	13	42	
			低	63.0	8	13	42	
104	胶州. 碧河站	#1主变	高	63.0	0	1	50	
			低	63.0	0	1	50	
		#2主变	高	63.0	7	10	44	

		#4主变	低	63.0	7	10	44	
105	胶州. 三里河站	#1主变	高	63.0	3	4	48	
			低	63.0	3	4	48	
		#2主变	高	63.0	4	7	46	
			低	63.0	4	7	46	
106	莱西. 北全站	#1主变	高	31.5	22	69	4	
			中	31.5	1	3	4	
			低	31.5	21	66	4	
		#2主变	高	50.0	28	56	12	
			中	50.0	9	19	12	
			低	50.0	20	40	12	
107	莱西. 店埠站	#1主变	高	50.0	31	62	9	业扩及夏季空调负荷增加
			中	50.0	19	38	9	业扩及夏季空调负荷增加
			低	50.0	13	27	9	业扩及夏季空调负荷增加
		#2主变	高	50.0	22	45	18	业扩及夏季空调负荷增加
			中	50.0	8	16	18	
			低	50.0	15	31	18	业扩及夏季空调负荷增加
108	莱西. 范家疃站	#1主变	高	50.0	12	24	28	
			低	50.0	12	24	28	
		#2主变	高	50.0	16	32	24	业扩及夏季空调负荷增加
			低	50.0	16	32	24	业扩及夏季空调负荷增加
			高	50.0	16	32	24	

109	莱西. 姜山站	#1主变	中	50.0	0	0	24	
			低	50.0	16	31	24	
		#2主变	高	50.0	15	30	25	
			中	50.0	9	18	25	
			低	50.0	12	24	25	
110	莱西. 龙水站	#1主变	高	50.0	37	74	3	业扩及夏季空调负荷增加
			中	50.0	2	4	3	
			低	50.0	37	73	3	业扩及夏季空调负荷增加
		#2主变	高	50.0	27	53	13	
			中	50.0	5	10	13	
			低	50.0	26	52	13	业扩及夏季空调负荷增加
		#3主变	高	63.0	17	27	33	业扩及夏季空调负荷增加
			低	63.0	17	27	33	业扩及夏季空调负荷增加
111	莱西. 梅花山站	#1主变	高	50.0	27	54	13	业扩及夏季空调负荷增加
			低	50.0	27	54	13	业扩及夏季空调负荷增加
		#2主变	高	50.0	23	45	17	业扩及夏季空调负荷增加
			低	50.0	23	45	17	业扩及夏季空调负荷增加
112	莱西. 南岚站	#1主变	高	31.5	17	55	8	业扩及夏季空调负荷增加
			中	31.5	13	42	8	业扩及夏季空调负荷增加
			低	31.5	5	15	8	
		#2主变	高	50.0	23	47	17	业扩及夏季空调负荷增加
			中	50.0	22	45	17	业扩及夏季空调负荷增加

			低	50.0	1	3	17	业扩及夏季空调负荷增加
113	莱西.南墅站	#1主变	高	31.5	19	62	6	业扩及夏季空调负荷增加
			中	31.5	2	8	6	业扩及夏季空调负荷增加
			低	31.5	19	59	6	业扩及夏季空调负荷增加
		#2主变	高	50.0	28	55	12	业扩及夏季空调负荷增加
			中	50.0	6	12	12	
			低	50.0	24	47	12	业扩及夏季空调负荷增加
114	莱西.水集站	#1主变	高	50.0	31	62	9	
			中	50.0	/	/	/	
			低	50.0	31	62	9	
		#2主变	高	50.0	42	84	0	
			中	50.0	10	20	0	
			低	50.0	33	66	0	
115	莱西.望城站	#1主变	高	31.5	24	77	1	
			中	31.5	9	29	1	
			低	31.5	16	51	1	
		#2主变	高	50.0	14	27	26	
			中	50.0	2	5	26	
			低	50.0	13	25	26	
116	莱西.武备站	#1主变	高	31.5	26	83	0	业扩及夏季空调负荷增加
			中	31.5	10	32	0	业扩及夏季空调负荷增加
			低	31.5	16	52	0	业扩及夏季空调负荷增加

110	米四. 武备站	#2主变	高	31.5	23	75	2	业扩及夏季空调负荷增加
			中	31.5	12	37	2	业扩及夏季空调负荷增加
			低	31.5	15	48	2	业扩及夏季空调负荷增加
117	莱西. 夏格庄站	#1主变	高	50.0	19	38	21	业扩及夏季空调负荷增加
			中	50.0	12	24	21	业扩及夏季空调负荷增加
			低	50.0	8	15	21	业扩及夏季空调负荷增加
		#2主变	高	50.0	20	40	20	业扩及夏季空调负荷增加
			中	50.0	6	13	20	业扩及夏季空调负荷增加
			低	50.0	14	27	20	业扩及夏季空调负荷增加
118	莱西. 院西站	#1主变	高	50.0	28	57	12	业扩及夏季空调负荷增加
			低	50.0	28	57	12	业扩及夏季空调负荷增加
		#2主变	高	50.0	29	59	11	业扩及夏季空调负荷增加
			低	50.0	29	59	11	业扩及夏季空调负荷增加
119	莱西. 秀山站	#1主变	高	50.0	8	16	32	业扩及夏季空调负荷增加
			低	50.0	8	16	32	业扩及夏季空调负荷增加
120	平度. 城东站	#1主变	高	63.0	49	78	1	
			中	63.0	34	53	1	
			低	63.0	21	33	1	
		#2主变	高	63.0	47	75	3	
			中	63.0	27	43	3	
			低	63.0	24	38	3	
			高	50.0	37	74	3	

121	平度. 城西站	#1主变	中	50.0	30	61	3	
			低	50.0	35	69	3	
		#2主变	高	50.0	36	72	4	
			中	50.0	19	38	4	
			低	50.0	21	42	4	
122	平度. 大驾埠站	#1主变	高	50.0	35	70	5	
			中	50.0	20	39	5	
			低	50.0	25	50	5	
		#2主变	高	50.0	28	56	12	
			中	50.0	15	30	12	
			低	50.0	20	40	12	
123	平度. 沟崖站	#1主变	高	50.0	19	38	21	
			中	50.0	3	5	21	
			低	50.0	15	30	21	
		#2主变	高	50.0	20	40	20	
			中	50.0	0	0	20	
			低	50.0	19	38	20	
124	平度. 河口站	#1主变	高	50.0	40	80	0	
			中	50.0	29	58	0	
			低	50.0	14	28	0	
		#2主变	高	50.0	36	71	4	
			中	50.0	25	50	4	

		#3主变	低	50.0	13	26	4	
			高	50.0	/	/	/	
			中	50.0	/	/	/	
			低	25.0	/	/	/	
125	平度. 洪山站	#1主变	高	50.0	34	68	6	
			中	50.0	37	74	3	
			低	50.0	5	11	6	
		#2主变	高	50.0	30	60	10	
			中	50.0	27	53	10	
			低	50.0	8	16	10	
126	平度. 灰埠站	#1主变	高	50.0	34	68	6	
			中	50.0	29	58	6	
			低	50.0	12	24	6	
		#2主变	高	50.0	33	65	7	
			中	50.0	26	52	7	
			低	50.0	15	29	7	
127	平度. 曲坊站	#1主变	高	50.0	26	51	14	
			低	50.0	26	51	14	
		#2主变	高	50.0	22	43	18	
			低	50.0	22	43	18	
		#1主变	高	50.0	21	41	19	
			中	50.0	9	18	19	

128	平度. 沙湾站		低	50.0	7	14	19	
		#2主变	高	50.0	29	59	11	
			中	50.0	19	37	11	
			低	50.0	13	25	11	
129	平度. 同和站	#1主变	高	50.0	43	85	0	
			中	50.0	18	36	0	
			低	50.0	27	55	0	
		#2主变	高	50.0	36	71	4	
			中	50.0	10	20	4	
			低	50.0	28	56	4	
130	平度. 香店站	#1主变	高	50.0	23	45	17	
			中	50.0	9	18	17	
			低	25.0	19	74	1	
		#2主变	高	50.0	30	60	10	
			中	50.0	18	36	10	
			低	50.0	16	31	10	
131	平度. 徐家庄站	#1主变	高	50.0	18	37	22	
			中	50.0	4	8	22	
			低	50.0	18	37	22	
		#2主变	高	50.0	15	30	25	
			中	50.0	4	8	25	
			低	50.0	13	26	25	

132	平度. 张舍站	#1主变	高	50.0	36	73	4	
			中	50.0	25	51	4	
			低	50.0	17	34	4	
		#2主变	高	50.0	20	41	20	
			中	50.0	6	12	20	
			低	50.0	13	25	20	
133	平度. 三合山站	#1主变	高	50.0	16	32	24	
			低	50.0	16	32	24	
		#2主变	高	50.0	19	39	21	
			低	50.0	18	35	21	
134	平度. 亭兰站	#1主变	高	63.0	16	25	34	
			低	63.0	16	25	34	
		#2主变	高	63.0	20	31	31	
			低	63.0	20	31	31	
135	平度. 围山站	#1主变	高	63.0	18	29	32	
			低	63.0	18	29	32	
		#2主变	高	63.0	12	19	38	
			低	63.0	12	19	38	
136	平度. 秀水站	#1主变	高	63.0	23	37	27	
			低	63.0	23	37	27	
		#2主变	高	63.0	13	21	37	
			低	63.0	13	21	37	

137	平度. 幸福站	#1主变	高	63.0	/	/	/	
			低	63.0	/	/	/	
		#2主变	高	63.0	/	/	/	
			低	63.0	/	/	/	
138	安子站	#1主变	高	63.0	13	20	38	
			低	63.0	13	21	37	
		#2主变	高	63.0	8	13	42	
			低	63.0	8	13	42	
139	白沙河站	#1主变	高	63.0	17	27	33	
			低	63.0	17	27	33	
		#2主变	高	63.0	20	32	30	
			低	63.0	20	32	30	
		#3主变	高	63.0	9	14	41	
			低	63.0	9	14	41	
140	古岛站	#1主变	高	63.0	14	22	36	
			低	63.0	14	22	36	
		#2主变	高	63.0	16	26	34	
			低	63.0	16	26	34	
141	宏顺站	#1主变	高	63.0	13	20	38	
			低	63.0	13	20	38	
		#2主变	高	63.0	14	22	37	
			低	63.0	14	22	37	

142	江山南站	#1主变	高	63.0	18	29	32	
			低	63.0	18	29	32	
		#2主变	高	63.0	16	25	35	
			低	63.0	16	25	35	
143	上庄站	#1主变	高	63.0	16	25	34	
			低	63.0	16	22	34	
		#2主变	高	63.0	13	21	37	
			低	63.0	13	20	37	
144	怡海站	#1主变	高	63.0	9	15	41	
			低	63.0	9	22	41	
		#2主变	高	63.0	13	21	37	
			低	63.0	13	21	37	
145	盐田站	#1主变	高	63.0	31	49	19	
			低	63.0	31	49	19	
		#2主变	高	63.0	24	38	27	
			低	63.0	24	38	26	

35千伏变电站主变负荷开放信息

说明：

1. 主变可开放容量=主变额定容量*0.8-上年度至上月出现过的最大负荷（正常方式）-本月新接入的负荷+本月转走的负荷。
2. 主变中、低压侧可开放容量不得大于高压侧可开放容量。
3. 主变中、低压侧可开放容量不具备同时性，同时接入容量不得大于高压侧可开放容量。
4. 可开放容量每月滚动更新，对新建变电站、主变增容、主变扩建、新出线路、线路改接等造成可开放容量变化时，应在备注中注明。

序号	变电站	变压器	主变绕组	额定容量 (MVA)	最高负荷 (MVA)	负载率 (%)	可开放容量 (MVA)	备注
188	安徽路站	#1主变	低	31.50	14	43	12	
		#2主变	低	31.50	12	38	13	
189	澳门路站	#1主变	低	12.50	1	6	9	
		#2主变	低	12.50	2	5	8	
190	百通馨苑站	#1主变	低	31.50	29	93	0	
		#2主变	低	31.50	23	74	2	
191	北宅站	#1主变	低	31.50	14	44	11	
		#2主变	低	31.50	24	77	1	
192	北庄站	#1主变	低	31.50	6	17	20	
		#2主变	低	31.50	6	18	20	
193	滨海站	#1主变	低	31.50	9	29	16	
		#2主变	低	31.50	11	36	14	
194	城区站	#1主变	低	20.00	11	56	5	
		#2主变	低	20.00	16	79	0	
195	错埠岭站	#1主变	低	31.50	23	73	2	
		#2主变	低	31.50	20	62	6	

196	北岭站	#1主变	低	31.50	20	63	5	
		#2主变	低	31.50	22	71	3	
		#3主变	低	31.50	18	57	7	
197	大港站	#1主变	低	20.00	8	42	8	
		#2主变	低	20.00	17	85	0	
		#3主变	低	20.00	12	60	4	
198	大连路站	#1主变	低	31.50	13	42	12	
		#2主变	低	31.50	24	75	2	
199	大湛山站	#1主变	低	31.50	13	42	12	
		#2主变	低	31.50	13	40	13	
200	丹山站	#1主变	低	20.00	15	73	1	
		#2主变	低	20.00	7	34	9	
201	东海路站	#1主变	低	31.50	6	19	19	
		#2主变	低	31.50	10	32	15	
		#3主变	低	31.50	13	42	12	
		#4主变	低	31.50	13	40	13	
202	东韩站	#1主变	低	20.00	11	54	5	
		#2主变	低	20.00	14	70	2	
203	浮山后站	#1主变	低	20.00	9	43	7	
		#2主变	低	20.00	11	54	5	
204	福岭工业园站	#1主变	低	31.50	23	74	2	
		#2主变	低	31.50	18	56	7	

205	福州路站	#1主变	低	31.50	11	34	15	
		#2主变	低	31.50	15	49	10	
		#3主变	低	31.50	20	63	5	
206	抚顺路站	#1主变	低	20.00	13	64	3	
		#2主变	低	20.00	4	22	12	
207	高新工业园站	#1主变	低	31.50	15	47	10	
		#2主变	低	31.50	13	40	12	
208	广水路站	#1主变	低	31.50	21	67	4	
		#2主变	低	31.50	24	76	1	
209	贵州路站	#1主变	低	31.50	16	49	10	
		#2主变	低	31.50	15	49	10	
210	海泊河站	#1主变	低	20.00	15	75	2	
		#2主变	低	31.50	14	45	11	
		#3主变	低	20.00	7	35	9	
211	海尔路站	#1主变	低	31.50	11	35	14	
		#2主变	低	31.50	16	50	10	
212	海景站	#1主变	低	31.50	15	48	10	
		#2主变	低	31.50	18	57	7	
213	杭州路站	#1主变	低	31.50	16	52	9	
		#2主变	低	31.50	14	43	12	
214	河套站	#1主变	低	20.00	10	50	6	
		#2主变	低	20.00	17	83	0	

215	红岛站	#1主变	低	31.50	11	36	14	
		#2主变	低	31.50	10	33	15	
216	红石崖站	#1主变	低	31.50	4	12	21	
		#2主变	低	31.50	5	16	20	
217	湖岛站	#1主变	低	31.50	11	36	14	
		#2主变	低	31.50	13	40	13	
218	虎苑站	#1主变	低	31.50	26	83	0	
		#2主变	低	31.50	21	67	4	
219	环城南路站	#1主变	低	31.50	21	68	4	
		#2主变	低	31.50	20	64	5	
220	环山站	#1主变	低	31.50	9	30	16	
		#2主变	低	31.50	11	35	14	
		#3主变	低	31.50	8	24	18	
221	环宇站	#1主变	低	31.50	15	48	10	
		#2主变	低	31.50	12	38	13	
222	黄岛站	#1主变	低	20.00	15	74	1	
		#2主变	低	20.00	17	84	0	
223	汇泉站	#1主变	低	31.50	13	41	12	
		#2主变	低	31.50	18	56	7	
224	嘉定路站	#1主变	低	20.00	18	88	0	
		#2主变	低	20.00	15	74	1	
225	金家岭站	#1主变	低	31.50	20	63	5	

225	金家岭站	#2主变	低	31.50	10	32	15	
226	九水路站	#1主变	低	31.50	21	66	4	
		#2主变	低	31.50	17	55	8	
227	李沧东部站	#1主变	低	31.50	18	56	7	
		#2主变	低	31.50	12	39	13	
228	李村站	#1主变	低	31.50	24	77	1	
		#2主变	低	31.50	26	81	0	
		#3主变	低	31.50	26	82	0	
229	李沙站	#1主变	低	20.00	14	72	2	
		#2主变	低	20.00	13	65	3	
		#3主变	低	20.00	14	69	2	
230	连云港路站	#1主变	低	31.50	15	47	10	
		#2主变	低	31.50	15	47	10	
231	辽宁路站	#1主变	低	31.50	12	39	13	
		#2主变	低	31.50	12	38	13	
232	临港站	#1主变	低	31.50	17	55	8	
		#2主变	低	31.50	18	59	7	
233	流清河站	#1主变	低	31.50	19	59	7	
		#2主变	低	31.50	14	43	12	
234	流亭站	#1主变	低	31.50	21	67	4	
		#2主变	低	31.50	16	51	9	
235	柳花站	#1主变	低	20.00	9	45	7	

235	柳化路站	#2主变	低	20.00	11	55	5	
236	娄山站	#1主变	低	20.00	18	90	0	
		#2主变	低	31.50	19	60	6	
237	麦岛站	#1主变	低	31.50	16	51	9	
		#2主变	低	31.50	25	79	0	
238	梅岭站	#1主变	低	31.50	15	48	10	
		#2主变	低	31.50	12	38	13	
239	苗岭路站	#1主变	低	31.50	11	36	14	
		#2主变	低	31.50	15	49	10	
240	南山站	#1主变	低	20.00	13	67	3	
		#2主变	低	20.00	12	59	4	
241	宁德路站	#1主变	低	31.50	14	44	11	
		#2主变	低	31.50	20	63	5	
242	宁夏路站	#1主变	低	20.00	17	87	0	
		#2主变	低	31.50	17	54	8	
		#3主变	低	20.00	16	80	0	
243	女姑口站	#1主变	低	31.50	14	43	12	
		#2主变	低	20.00	13	67	3	
244	普集路站	#1主变	低	31.50	3	10	22	
		#2主变	低	31.50	4	13	21	
245	青大站	#1主变	低	31.50	16	50	9	
		#2主变	低	31.50	18	57	7	

246	清江路站	#1主变	低	31.50	22	69	4	
		#2主变	低	31.50	17	55	8	
247	瑞昌站	#1主变	低	31.50	15	47	10	
		#2主变	低	31.50	15	48	10	
248	沙子口站	#1主变	低	20.00	10	51	6	
		#2主变	低	20.00	16	80	0	
249	山东路站	#1主变	低	31.50	19	62	6	
		#2主变	低	31.50	28	87	0	
		#3主变	低	31.50	18	56	8	
250	上海路站	#1主变	低	20.00	10	50	6	
		#2主变	低	20.00	11	55	5	
251	尚佳站	#1主变	低	31.50	15	47	10	
		#2主变	低	31.50	6	19	19	
252	深圳站	#1主变	低	31.50	21	68	4	
		#2主变	低	31.50	22	69	3	
253	升平路站	#1主变	低	20.00	14	72	0	
		#2主变	低	20.00	16	80	0	
254	石老人站	#1主变	低	31.50	16	51	9	
		#2主变	低	31.50	17	54	8	
		#3主变	低	31.50	12	38	13	
255	世园站	#1主变	低	31.50	9	29	16	
		#2主变	低	31.50	7	22	18	

		#3主变	低	31.50	6	20	19	
256	市南软件园站	#1主变	低	31.50	10	32	15	
		#2主变	低	31.50	10	31	15	
257	书院站	#1主变	低	31.50	23	74	2	
		#2主变	低	31.50	24	76	1	
258	四流南路站	#1主变	低	31.50	19	60	6	
		#2主变	低	31.50	16	50	9	
259	松岭站	#1主变	低	31.50	10	30	16	
		#2主变	低	31.50	17	53	9	
260	台东站	#1主变	低	31.50	13	41	12	
		#2主变	低	31.50	14	46	11	
261	台柳路站	#1主变	低	31.50	14	43	12	
		#2主变	低	31.50	13	41	12	
262	台西站	#1主变	低	31.50	16	49	10	
		#2主变	低	31.50	14	43	12	
263	太平角	#1主变	低	31.50	22	68	4	
		#2主变	低	31.50	23	74	2	
264	天山站	#1主变	低	20.00	10	48	6	
		#2主变	低	20.00	13	65	3	
265	天泰奥园站	#1主变	低	31.50	22	70	3	
		#2主变	低	31.50	19	60	6	
266	同安路站	#1主变	低	31.50	24	77	1	

200	同文路站	#2主变	低	31.50	15	49	10	
267	王戈庄站	#1主变	低	20.00	18	90	0	
		#2主变	低	20.00	18	90	0	
		#3车载变	低	20.00	14	68	2	
		#4车载变	低	20.00	9	45	7	
268	蔚蓝海岸站	#1主变	低	31.50	11	35	14	
		#2主变	低	31.50	15	47	11	
269	文昌阁站	#1主变	低	31.50	21	67	4	
		#2主变	低	31.50	26	83	0	
		#3主变	低	31.50	21	67	4	
270	西韩站	#1主变	低	31.50	15	48	10	
		#2主变	低	31.50	17	54	8	
271	惜福镇站	#1主变	低	31.50	16	51	9	
		#2主变	低	20.00	18	89	0	
272	夏庄站	#1主变	低	31.50	26	83	0	
		#2主变	低	31.50	24	75	2	
273	香港路站	#1主变	低	31.50	17	55	8	
		#2主变	低	31.50	16	50	10	
274	小村庄站	#1主变	低	20.00	12	61	4	
		#2主变	低	20.00	14	70	2	
		#3主变	低	20.00	13	64	3	
275	小港站	#1主变	低	50.00	18	36	22	

275	小港站	#2主变	低	50.00	12	25	28	
276	辛家庄站	#1主变	低	31.50	22	70	3	
		#2主变	低	31.50	28	88	0	
277	兴隆路站	开关站	——	——	——	——	——	
278	徐州路站	#1主变	低	31.50	12	37	14	
		#2主变	低	31.50	14	45	11	
279	延川站	#1主变	低	31.50	15	49	10	
		#2主变	低	31.50	18	57	7	
280	盐城路站	#1主变	低	31.50	15	48	10	
		#2主变	低	31.50	16	50	9	
281	宜阳站	#1主变	低	31.50	19	59	6	
		#2主变	低	31.50	19	61	6	
282	银川路站	#1主变	低	31.50	7	23	18	
		#2主变	低	31.50	8	26	17	
283	游岛站	#1主变	低	31.50	9	28	16	
		#2主变	低	31.50	14	44	11	
284	远涛站	#1主变	低	20.00	0	0	16	
		#2主变	低	20.00	0	0	16	
285	云南路站	#1主变	低	31.50	15	47	10	
		#2主变	低	31.50	15	47	10	
286	湛流干站	#1主变	低	20.00	12	58	4	
		#2主变	低	31.50	15	47	10	

		#3主变	低	31.50	17	54	8	
287	长沙路站	#1主变	低	31.50	22	71	3	
		#2主变	低	31.50	19	62	6	
288	周口路站	#1主变	低	20.00	12	58	4	
		#2主变	低	20.00	16	78	0	
289	株洲站	#1主变	低	31.50	10	31	16	
		#2主变	低	31.50	12	37	14	
290	黄岛. 宝山站	#1主变	低	10.00	6	57	2	
		#2主变	低	12.50	5	40	5	
291	黄岛. 城北站	#1主变	低	20.00	14	70	2	
		#2主变	低	20.00	13	65	3	
292	黄岛. 大场站	#1主变	低	20.00	11	55	5	
		#2主变	低	20.00	7	35	9	
293	黄岛. 大村站	#1主变	低	16.00	7	44	6	
		#2主变	低	20.00	9	43	8	
294	黄岛. 大珠山	#1主变	低	20.00	6	28	10	
		#2主变	低	20.00	7	37	9	
295	黄岛. 海青站	#1主变	低	20.00	6	30	10	
		#2主变	低	20.00	9	43	8	
296	黄岛. 六汪站	#1主变	低	20.00	8	40	8	
		#2主变	低	16.00	14	84	0	
297	黄岛. 南河站	#1主变	低	20.00	16	80	0	

297	黄岛. 南村站	#2主变	低	20.00	9	45	7	
298	黄岛. 沙沟站	#1主变	低	20.00	12	60	4	
		#2主变	低	20.00	12	60	4	
299	黄岛. 西郊站	#1主变	低	20.00	16	80	0	
		#2主变	低	20.00	15	75	1	
300	黄岛. 向阳站	#1主变	低	20.00	13	65	3	
		#2主变	低	20.00	12	60	4	
301	黄岛. 营前站	#1主变	低	10.00	7	65	2	
		#2主变	低	20.00	9	43	0	
302	黄岛. 张家楼	#1主变	低	20.00	16	80	0	
		#2主变	低	20.00	9	45	7	
303	即墨. 搀山站	#1主变	低	31.50	8	24	18	主变增容
		#2主变	低	31.50	7	21	19	主变增容
304	即墨. 段泊岚站	#1主变	低	16.00	13	81	0	线路割接
		#2主变	低	16.00	7	44	6	线路割接
305	即墨. 段村站	#1主变	低	20.00	16	80	0	负荷调整
		#2主变	低	20.00	14	70	2	
306	即墨. 丰城站	#1主变	低	20.00	7	35	9	
		#2主变	低	20.00	7	33	9	主变增容
307	即墨. 服装园站	#1主变	低	31.50	23	73	2	10kV母线载流量受限
		#2主变	低	20.00	16	82	0	
308	即墨. 化山站	#1主变	低	20.00	5	25	11	负荷割接及光伏增加

308	即墨. 牛山站	#2主变	低	20.00	13	65	3	负荷割接及光伏增加
309	即墨. 环秀站	#1主变	低	31.50	23	73	2	10kV母线载流量受限
		#2主变	低	31.50	24	76	1	10kV母线载流量受限
310	即墨. 灵山站	#1主变	低	20.00	7	35	9	光伏增加
		#2主变	低	20.00	14	70	2	
311	即墨. 楼子疃站	#1主变	低	16.00	11	70	2	
		#2主变	低	16.00	8	50	5	线路割接
312	即墨. 墨城站	#1主变	低	20.00	16	79	0	
		#2主变	低	20.00	14	69	2	主变增容
313	即墨. 七级站	#1主变	低	20.00	5	25	11	
		#2主变	低	20.00	10	50	6	
314	即墨. 市东站	#1主变	低	20.00	15	75	1	
		#2主变	低	31.50	21	65	5	10kV母线载流量受限
315	即墨. 市西站	#1主变	低	20.00	15	77	1	
		#2主变	低	20.00	15	77	1	
316	即墨. 王村站	#1主变	低	16.00	6	36	7	
		#2主变	低	16.00	6	38	7	
317	即墨. 温泉站	#1主变	低	20.00	16	80	0	
		#2主变	低	20.00	6	30	10	
318	即墨. 西城站	#1主变	低	20.00	15	75	1	
		#2主变	低	20.00	15	75	1	
319	即墨. 移风站	#1主变	低	16.00	11	66	2	

319	即墨. 移风站	#2主变	低	16.00	10	63	3	
320	即墨. 长直站	#1主变	低	20.00	13	65	3	
		#2主变	低	10.00	6	60	2	
321	胶州. 城里站	#1主变	低	25.00	20	79	0	
		#2主变	低	20.00	12	59	4	
322	胶州. 东环站	#1主变	低	20.00	14	71	3	
		#2主变	低	20.00	19	88	0	
323	胶州. 杜村站	#1主变	低	20.00	12	61	4	
		#2主变	低	20.00	12	61	4	
324	胶州. 后屯站	#1主变	低	20.00	18	88	0	
		#2主变	低	20.00	16	82	0	
325	胶州. 后王站	#1主变	低	20.00	19	95	0	
		#2主变	低	20.00	16	78	0	
326	胶州. 胶莱站	#1主变	低	20.00	14	70	2	
		#2主变	低	20.00	18	91	0	
327	胶州. 九龙站	#1主变	低	20.00	16	81	0	
		#2主变	低	20.00	16	79	0	
		#3主变	低	20.00	9	43	7	
328	胶州. 里岔站	#1主变	低	10.00	9	87	0	
		#2主变	低	20.00	10	50	6	
329	胶州. 柳州站	#1主变	低	0.00	0	0	0	
		#2主变	低	4.00	3	74	0	

330	胶州. 胜利站	#1主变	低	20.00	12	58	4	
		#2主变	低	20.00	13	63	4	
		#3主变	低	20.00	13	64	3	
331	胶州. 扬州路站	#1主变	低	25.00	17	67	3	
		#2主变	低	20.00	15	77	1	
332	胶州. 洋河站	#1主变	低	20.00	6	28	10	
		#2主变	低	10.00	6	64	2	
333	胶州. 营房站	#1主变	低	20.00	8	40	8	
		#2主变	低	20.00	11	57	5	
334	胶州. 苑戈庄站	#1主变	低	20.00	9	46	7	
		#2主变	低	20.00	7	36	9	
335	胶州. 张家屯站	#1主变	低	10.00	7	68	1	
		#2主变	低	20.00	10	51	6	
336	胶州. 朱戈站	#1主变	低	20.00	11	56	5	
		#2主变	低	20.00	13	63	3	
337	莱西. 昌阳站	#1主变	低	10.00	2	19	6	
		#2主变	低	10.00	3	33	5	
338	莱西. 河头店站	#1主变	低	10.00	5	48	3	
		#2主变	低	16.00	7	43	6	业扩及夏季空调负荷增加
339	莱西. 李权庄站	#1主变	低	20.00	11	56	5	业扩及夏季空调负荷增加
		#2主变	低	20.00	8	40	8	
340	莱西. 书口路站	#1主变	低	20.00	12	58	4	

340	莱西. 龙口岭站	#2主变	低	20.00	9	47	7	
341	莱西. 马连庄站	#1主变	低	10.00	3	28	5	
		#2主变	低	20.00	7	35	9	业扩及夏季空调负荷增加
342	莱西. 牛溪埠站	#1主变	低	20.00	8	41	8	业扩及夏季空调负荷增加
		#2主变	低	12.50	6	47	4	
343	莱西. 朴木站	#1主变	低	20.00	12	61	4	业扩及夏季空调负荷增加
		#2主变	低	20.00	8	42	8	业扩及夏季空调负荷增加
344	莱西. 绕岭站	#1主变	低	20.00	7	35	9	
		#2主变	低	20.00	7	34	9	业扩及夏季空调负荷增加
345	莱西. 日庄站	#1主变	低	8.00	5	62	1	
		#2主变	低	10.00	8	76	0	业扩及夏季空调负荷增加
346	莱西. 孙受站	#1主变	低	20.00	6	32	10	业扩及夏季空调负荷增加
		#2主变	低	20.00	10	48	6	业扩及夏季空调负荷增加
347	莱西. 唐家庄站	#1主变	低	20.00	4	19	12	
		#2主变	低	10.00	3	32	5	业扩及夏季空调负荷增加
348	莱西. 院里站	#1主变	低	10.00	2	24	6	
		#2主变	低	10.00	3	34	5	
349	莱西. 院上站	#1主变	低	20.00	7	36	9	
		#2主变	低	20.00	9	43	7	
350	平度. 崔家集站	#1主变	低	20.00	16	82	0	
		#2主变	低	20.00	16	81	0	
351	平度. 十四站	#1主变	低	20.00	9	46	0	

351	平度. 八田站	#2主变	低	20.00	10	49	0	
352	平度. 大泽山站	#1主变	低	20.00	6	30	10	
		#2主变	低	20.00	10	49	6	
353	平度. 店子站	#1主变	低	20.00	16	80	0	
		#2主变	低	20.00	15	74	1	
354	平度. 古岬站	#1主变	低	20.00	14	72	2	
		#2主变	低	10.00	9	91	0	
355	平度. 崮山站	#1主变	低	10.00	8	75	1	
		#2主变	低	10.00	6	63	2	
356	平度. 广州路站	#1主变	低	20.00	16	79	0	
		#2主变	低	31.50	15	46	11	
357	平度. 宏泰站	#1主变	低	6.30	3	44	2	
		#2主变	低	10.00	6	59	2	
358	平度. 华里站	#1主变	低	10.00	8	84	0	
		#2主变	低	8.00	9	118	0	
359	平度. 旧店站	#1主变	低	20.00	8	41	8	
		#2主变	低	20.00	15	75	1	
360	平度. 兰底站	#1主变	低	10.00	8	81	0	
		#2主变	低	20.00	16	80	0	
361	平度. 蓼兰站	#1主变	低	20.00	8	39	8	
		#2主变	低	20.00	16	80	0	
362	平度. 蓼兰站	#1主变	低	8.00	5	63	1	

362	平度. 林二站	#2主变	低	10.00	4	43	4	
363	平度. 门村站	#1主变	低	10.00	8	76	0	
		#2主变	低	10.00	3	25	6	
364	平度. 庙西站	#1主变	低	20.00	10	50	6	
		#2主变	低	20.00	15	75	1	
365	平度. 明村站	#1主变	低	10.00	7	67	1	
		#2主变	低	20.00	15	74	1	
366	平度. 南村站	#1主变	低	20.00	13	66	3	
		#2主变	低	20.00	17	84	0	
		#3主变	低	10.00	10	96	0	
367	平度. 前楼站	#1主变	低	20.00	18	92	0	
		#2主变	低	20.00	14	69	2	
368	平度. 仁兆站	#1主变	低	31.50	18	56	8	
		#2主变	低	20.00	15	77	1	
369	平度. 三堤站	#1主变	低	20.00	8	41	8	
		#2主变	低	20.00	14	69	2	
370	平度. 石泉站	#1主变	低	20.00	7	34	9	
		#2主变	低	10.00	5	54	3	
371	平度. 苏州路站	#1主变	低	20.00	15	74	0	
		#2主变	低	20.00	8	39	8	
372	平度. 天津路站	#1主变	低	31.50	17	54	8	
		#2主变	低	20.00	17	83	0	

373	平度. 田庄站	#1主变	低	20.00	18	89	0	
		#2主变	低	20.00	15	75	1	
374	平度. 亭口站	#1主变	低	20.00	5	23	11	
		#2主变	低	10.00	8	76	0	
375	平度. 同辉路站	#1主变	低	10.00	0	0	8	
		#2主变	低	10.00	4	39	4	
376	平度. 万家站	#1主变	低	20.00	15	74	1	
		#2主变	低	20.00	15	75	1	
377	平度. 新河站	#1主变	低	10.00	8	76	0	
		#2主变	低	10.00	5	53	3	
378	平度. 云山村	#1主变	低	10.00	7	71	1	
		#2主变	低	10.00	8	78	0	
379	平度. 张戈庄站	#1主变	低	20.00	17	85	0	
		#2主变	低	20.00	11	56	5	
380	平度. 长乐站	#1主变	低	20.00	13	63	4	
		#2主变	低	10.00	8	76	0	
381	平度. 镇江路站	#1主变	低	20.00	14	70	2	
		#2主变	低	31.50	14	43	12	
382	平度. 郑州路站	#1主变	低	20.00	16	80	0	
		#2主变	低	20.00	15	77	1	
383	平度. 中庄站	#1主变	低	20.00	14	72	2	
		#2主变	低	20.00	8	40	8	

384	平度. 祝沟站	#1主变	低	20.00	9	44	7	
		#2主变	低	10.00	7	65	2	
385	平度. 茶山站	#1主变	低	31.50	6	19	19	
		#2主变	低	20.00	5	24	11	
386	标山站	#1主变	低	31.50	15	47	10	
		#2主变	低	31.50	14	45	11	
387	福临站	#1主变	低	31.50	6	20	19	
		#2主变	低	31.50	8	24	18	
388	海宁站	#1主变	低	31.50	4	12	21	
		#2主变	低	31.50	4	14	21	
		#3主变	低	31.50	2	6	23	
389	石湾站	#1主变	低	31.50	10	32	15	
		#2主变	低	31.50	3	10	22	
390	朱家站	#1主变	低	31.50	4	12	22	
		#2主变	低	31.50	3	9	22	